

**1**


Plug both devices into the mains

**2**


Connect your equipments



RECOMMENDED USE OF A MULTIPLE PLUG ADAPTER



For more information about the way to secure your network or to join a HomePlug AV network, please consult the User Guide available on the <http://support.sagemcom.com> website.



Device is **OFF**.

Device is **ON**.


Ethernet port is **not** connected.

Ethernet port is **connected**.

No device detected on your network.

At least one device is detected on your network.

Note: For more information about the status of the LEDs, please consult the User Guide available on the <http://support.sagemcom.com> website.



Ethernet port

Use the Ethernet port to connect your equipments using the Ethernet cable provided.

Pairing button

Press this button to secure your network.

Reset button

Press this button to restore factory settings.

Note: For a detailed procedure on how to secure your network or add additional devices to an existing powerline network, please consult the User Guide available on the <http://support.sagemcom.com> website.

SAGEMCOM

Sagemcom Broadband SAS

Headquarters: 250, route de l'Empereur

92848 Rueil-Malmaison Cedex - FRANCE

Tel: +33 (0)1 57 61 10 00 - Fax: +33 (0)1 57 61 10 01

www.sagemcom.com